

MANUAL INSTRUCTION

BEFORE INSTALLATION

Before installation apply the first coat of Wood Oil. The Oil should be applied to both sides of the Wood panel and all edges and tap holes that have been cut. Let the Wood panel soak up as much Oil as possible.

Cut ends, holes and end grains require three natural Oil applications prior to fitting.

Note: Once the Wood panel has been fitted cut ends and holes will be in accessible and must be well oiled prior to installation. Wood is a natural product and will expand and contract. Wood can be affected by heat & humidity.

When deciding on an oil first test in an inconspicuous area (if needed) for the desired finish.

STORAGE OF WOOD PANELS

When storing: The Wood panels should be stored flat. Wood panels must be fully supported at all times & kept away from any direct heat source. i.e. radiators. Please note: Never store vertically or on a direct heat source or the Wood panel will start to bow. If the Wood panel has bowed, turn the Wood panel upside down for a day or so horizontally and it will straighten out. Do not place where the benchtop will be in direct sunlight.

Acclimatization: Immediately prior to installation the panels must be laid flat and be allowed to acclimatize in the room where they will be fitted, for a minimum period of 48 hours before fitting. Protect the panels from extreme changes in temperature and humidity. This acclimatization period is ideal for applying

natural oil to end grains and cuts, where future access will be a problem.

Room preparation: Please ensure that any Plastering or Plumbing required is complete and that this has been allowed to dry prior to installing the Wood panel.

FITTING A WORKTOP OR PANEL

Expansion gaps and silicone sealant

Solid Wood is a living material that will expand and shrink with temperature and humidity variances. Always leave a 5mm expansion gap to all other dead surfaces such as Stone, Steel, Walls and Pipes. Use a quality expandable silicone sealant when fitting and filling expansion gaps. It is recommended to use only the best quality silicone sealant (white or clear) where required.

Wood Panel installation – Fixing to cabinets

Angle brackets should be used to secure the Wood panel to the carcass. The elongated hole of the bracket needs to be screwed to the underside of the Wood panel. Always use washers with the screws to allow for humidity expansion changes.

Cutting the wood panel

When using the fine-toothed panel saw, cut panel with Wood panel face upwards. When using a jigsaw, saw cut panel with face downwards. Cut requires at least three oil applications before fitting.

Fitting the wood panel

Your Wood panel naturally wants to warp and bend when exposed to changing humidity and temperature. To avoid this, solid tight fitting to the surrounding surfaces is required. Secure the Wood panel with angle brackets and screws every 20cm on all sides! Use the angle brackets to the wall side if there is no cabinet to fix the Wood panel to. Pre-drill holes in the Wood panel where screws are required to ease tension. Screws should penetrate the Wood panel by a minimum of 15mm.

Fixing to brickwork

When fixing a Wood panel to a brick pier you must ensure that the brickwork is complete dry. As a precaution glue a damp proof barrier foil to the side or underside of the Wood panel that has already been well oiled and dried. Fix with adhesive. This will help form a moisture barrier between the Wood panel and brickwork. We also advise that alternate fixing points be made along the length of the Wood panel to prevent it from bowing.

Conner joints

When joining two Wood panels together it is recommended that both biscuit joints and standard Wood panel bolts are used to avoid temperature warping at a later stage. Treat the joining edge and the underneath of the Wood panel lavishly with oil before joining and fitting the Wood panels.

Inserting hobs, tiles, or stone materials

Always leave a 5mm expansion gap. Use silicone sealant when fitting and filling expansion gaps. The wood may crack if you do not allow for expansion gaps. Range cookers, such as AGA's, a minimum expansion gap of 40mm is required due to the constant heat source from these cookers.

Kitchen appliances

If a dishwasher or washing machine is to be installed under the Wood panel it is recommended to glue an insulation reflective foil and moisture barrier to be underside of the Wood panel to protect it from intense heat. A minimum 25mm gap should be allowed for ventilation above the appliance. Leave a 15mm gap between the end of tops and appliances, cut-outs for appliances and sinks.

Fitting an inset sink

This is the same procedure as with fitting laminate Wood panel! Expansion gaps must be left and sealed with silicone sealant. Take great care when installing sinks into timber Wood panels, due to the possibility of water penetration into the joints. When positioning and making a cut-out for a hob always follow the manufacturer's instructions of sizes, safety clearances, and sealing with silicone sealant.

Undermounting sinks

The skills required for undermounting Belfast type sinks in a solid hardwood Wood panel is best left to expert fitters.

Repair and long-term maintenance

After years of hard use your Wood panel may sustain some stains, scrapes & grazes. To refurbish your Wood panel, lightly sand it down with a sanding machine or with fine sandpaper. It will look like new again! For smaller areas of damage, sand locally and oil again.

CARE & MAINTENANCE

Wood oil prior to installation – Apply lavishly

Prior to installation you must generously Oil all the surfaces of the Wood panel paying particular attention to the underside and back edges. Once the Wood panel has been fitted these areas and cut edges may be inaccessible. We recommend that all cut edges and end grains will need a further 2 coats to ensure that the Oil has penetrated deep into the wood. When oiling remember to wipe away the excess oil after 15 minutes and then allow to dry for 6-8 hours prior to further applications. Please give special attention to the oiling of the end grains and cut ends to seal them properly. Apply the oil with a sponge or soft cloth. Never use steel wool to sand the surface as this may cause the Wood panel to become discolored when damp.

Ongoing maintenance of the Wood panel

In the first few weeks of use some care must be taken to prevent Wood panels becoming stained before they have built up sufficient protection. Avoid letting water build up on the worksurface, wipe off using a cloth. The Wood panels require to be oiled again within the first week of installation. Apply a thin coat of the same type of oil, leave for 15 minutes and then wipe off the excess. This is best done at night to allow maximum time for the Wood panel to dry off, overnight. After the first week, oiling once a week will suffice with the interval between treatments gradually increasing until eventually you are just wiping Wood panels with an oily cloth once a month or so to restore the sheen that has built up. As a useful hint, the Wood panel will need oiling when water on the surface smudges rather than forms a well-defined water droplet, or when the Wood panel feels dry.

WARRANTY

Each Wood panel is manufactured from selected material and is subject to stringent quality control procedures. The company cannot be held responsible for their further maintenance and installation, which is dependent upon the standard of work of individual contractors and the end user. No warranty is granted on fitted tops, mitered joints, or whether there is a lack of expansion or evaporating gaps. True factory faults are delamination of glue joints, which should not occur. Other potential faults discovered at a later stage after assembling and installation, such as cracked wood, bowing wood or deformed wood of any kind, appears due to that advice on installation and maintenance according to this leaflet has not been followed.

TIPS

Hot pans should be placed on a pan stand, trivet or similar and not directly onto the worksurface

Always use chopping board for food preparation, not the worksurface of the benchtop itself

Avoid letting water build up on the worksurface, wipe off using a cloth, if water is left to sit there will be a whitening of the surface. If a glass of water is left on the surface with water residue a white ring will

result. Wipe any water residue immediately. Acidic materials must be wiped up immediately, if left on the surface to soak in could leave a dull mark that may not be able to be repaired.

The surface should be cleaned with a warm damp cloth with a little washing up liquid

Re-oil your Wood panel and workstation regularly.

PRECAUTION

Cloths and sponges used when treating your Wood panel with oil may become FLAMMABLE!!! Please store or dispose of them safely.

INSTALLERS!

Please pass this leaflet to the end user.