

# Nouveau®

## Outdoor Chair Swing Kids Folded Ladybird



### Warning:


1. NOT suitable for children under 3 years.
2. Suitable for 4-8 year old children.
3. Completely unfold the chairs and engage locks before children use.
4. NEVER allow children to fold or unfold the chair before or after use, due to pinch points.
5. Take care NOT to get fingers caught when folding and unfolding the chairs and umbrella.
6. ONLY use on even surface.
7. DO NOT swing or balance on one leg support during seating.
8. DO NOT sit down suddenly as may break. Not suitable for last chair.
9. The chair is suitable for one person ONLY, DO NOT exceed the rated load of 50kg.
10. DO NOT exceed the rated load of 10kg for the table.
11. DO NOT stand on the product or use as a step ladder.
12. DO NOT place this product near a window where cords from blinds or curtains may be present as could cause choking hazard.
13. Be aware of the risk of open fires and other sources of strong heat in the vicinity of the product.
14. Move the product indoors during inclement weather, such as heavy rain, snow & wind.
15. The product will change color due to UV exposure and climate over time and this could happen quicker in some areas than others.
16. Failure to follow these safety tips could result in product damage, property loss, personal injury even death.

This manual applies to the following products

SKU:395044/Model:CK-074

# Nouveau®

## Outdoor Chair Swing Kids Folded Ladybird



This manual applies to the following products:

SKU:395044/Model:CK-074