


# DOME TENT SET UP GUIDE

PLEASE CHECK ALL PARTS ARE INCLUDED BEFORE ASSEMBLY COMMENCES. 2 PEOPLE RECOMMENDED FOR SET UP.



**1**

Assemble fibreglass poles (A and B). Attach poles to the tent sleeves using the coloured sleeve and fibreglass poles.

a) Find a flat location to setup the tent. Lay out the flysheet, inner tent and accessories ready for setup.  
 b) Assemble the 3 poles and insert them in the tent sleeves of the flysheet as pictured above.

**2**

Insert the poles into the 'ring and pin' located on the bottom of the flysheet as pictured above. The basic tent shape should now be formed.

**3**

Connect hooks to ring and connect T-hooks. Attach the inner tent to the flysheet using the T-hooks provided. Start from the centre hook at the top of the tent, then connect along each side. Attach the awning mat to the front of the tent using the hooks provided.

**4**


Connect T-hook to tie door. Secure the flysheet (F) to the ground using tent pegs (D) provided. Note: Insert the tent pegs (D) at 45° angle into the ground. Secure each guy rope to the ground using the tent pegs provided. Ensure to pull the guy rope tightly at an angle securing the rope into the ground before using the tent peg. Note: Insert the tent pegs (D) at 45° angle into the ground.

**KEEP THIS TENT AWAY FROM NAKED FLAMES AT ALL TIMES.**

Product Code: 382558

Model No.: LP-AB-DT250

VERSION: V2



# DOME TENT SET UP GUIDE

## IMPORTANT NOTICE

TENT SLEEPS UP TO 4 PERSON

**WARNING!** KEEP THIS TENT AWAY FROM NAKED FLAMES AT ALL TIMES.

### Care Instructions

- Do not machine wash
- Hand wash only
- Clean with a damp cloth and cold water
- Do not clean with soap, detergent, petrol, oil or solvents
- Do not iron
- Do not dry clean
- Lay on a flat surface to dry
- Ensure the tent is fully dry before storage

**NOTE:** If the tent gets wet during camping, shake as much water off as possible and pack away normally. It is important to set up the tent again within 24 hours of folding a wet tent even if it is raining. This will prevent mildew forming on the tent. To assist with the drying process, you may use an absorbent cloth or sponge to wipe down the tent. Air dry in sunlight as quickly as possible.

### FIRE AND VENTILATION PRECAUTIONS

- Do not use gas or other combustion appliances within this tent
- Do not place hot appliances near walls, roof or curtains
- Always observe the safety instructions for these appliances
- Never allow children to play near hot appliances
- Keep exits clear at all times
- Make sure you know the fire precaution arrangements on the site
- In an event of fire within the tent, exit the tent quickly through any openings and contact the site management
- Make sure ventilation openings are open to avoid suffocation
- Simply keep a minimum of 1 window or door open at all times

Product Code: 382558

Model No.: LP-AB-DT250

VERSION: V2