

Cleaning and Care

We recommend cleaning your letterbox regularly with warm soapy water.

To remove any stubborn marks, use a soft cloth and methylated spirits.

If the lock is left unused for some time, spray a lubricant like WD40 or CRC down the lock barrel, then push your letterbox key in and out of the lock several times.