Clean the surface using a soft cloth and methylated spirits to remove all dirt and residue.

Peel off double sided tape and press firmly onto clean surface.

The adhesive will cure over ten hours therefore press again firmly during this time to ensure a strong bond.

Style. Delivered.

boxdesign

New Zealand's Smartest Letterboxes.